



NOTES

1. PREPARE SOIL BEFORE INSTALLING EROSION MAT INCLUDING ALL SOIL PREPARATION AND SEEDING ACCORDING TO SPECIFICATIONS.
2. BEGIN AT TOP OF SLOPE BY ANCHORING MAT IN 6" WIDE BY 6" DEEP TRENCH, BACKFILL AND COMPACT TRENCH AFTER STAPLING.
3. ROLL THE EROSION MAT DOWN THE SLOPE.
4. THE EDGES OF PARALLEL EROSION MATS SHALL BE STAPLED WITH A 4" OVERLAP. USE ONLY BIODEGRADABLE STAPLES UNLESS SPECIFIED OTHERWISE.
5. WHEN EROSION MAT MUST BE SPLICED DOWN THE SLOPE, PLACE EROSION MAT END OVER END (SHINGLE STYLE) WITH 6" OVERLAY, STAPLE APPROX. 12" APART.
6. ALL EROSION MATS MUST BE SECURELY FASTENED TO THE SLOPE BY PLACING STAPLES/STAKES IN APPROPRIATE LOCATIONS AS RECOMMENDED BY THE MANUFACTURER.
7. SEE EROSION CONTROL PLANS FOR CLASS AND TYPES OF EROSION MAT.

EROSION MAT INSTALLATION
 C### NTS

State of Wisconsin
 Department of Administration
 Division of Facilities Development



DFD Civil Details Library

Sheet Title:
 EROSION MAT INSTALLATION

Revisions:

No.	Date:	Description:

Graphic Scale

DFD Number

Set Type

Date Issued 8/1/2017

Sheet Number