



PLAN VIEW

TRACKING PAD NOTES:

1. THE TRACKING PAD SHALL BE INSTALLED PRIOR TO ANY TRAFFIC LEAVING SITE.
2. STONE TRACKING PADS SHALL BE UNDERLAIN WITH A WISDOT TYPE R GEOTEXTILE FABRIC TO PREVENT MIGRATION OF UNDERLYING SOIL INTO THE SOIL.
3. SURFACE WATER MUST BE PREVENTED FROM PASSING THROUGH THE TRACKING PAD. FLOWS SHALL BE DIVERTED AWAY FROM TRACKING PADS OR CONVEYED UNDER AND AROUND THEM BY USING A VARIETY OF PRACTICES, SUCH AS CULVERTS, WATER BARS, OR SIMILAR PRACTICES.

TRACKING PAD NTS
C###

State of Wisconsin
 Department of Administration
 Division of Facilities Development



DFD Civil Details Library

Sheet Title:
TRACKING PAD

Revisions:

No.	Date:	Description:

Graphic Scale

DFD Number

Set Type

Date Issued **8/1/2017**

Sheet Number